

Canon **CAMERA HOLDER F2**

Instructions
使用説明書

Canon Camera Holder F2 is used in combination with a tripod or a copy apparatus to hold the camera in a stable, center of gravity position. Changing the camera to a horizontal or vertical position can be easily performed. This holder is very effective when a telephoto lens is used on the camera, making it comparatively heavy towards the front.

- Cameras on which Camera Holder F2 can be used: F-1, EF, FTb, FTQL, Pellix QL, Pellix, EX-Auto, FX and FP.
- Attachment screw position: The attachment screw of the camera holder is of the groove-shaped type so that it can move according to the different positions of the screw holes on the various cameras.
- Always use a cable release when shooting with a slow shutter speed. Two Canon cable releases of different lengths are available.

Subject to alterations.

キヤノン カメラホルダー F2

カメラホルダーF2は三脚あるいは、複写装置使用時に併用し、重心位置で安定させることができ、横位置、縦位置の変更も容易で、しかも堅固に取付けできるアクセサリーです。比較的重く前方に突き出す望遠レンズ使用の場合などには最も効果的です。

- 使用できるカメラ：F-1, EF, FTb, EX-Auto, FT QL, PELLIX QL, PELLIX, FX, FP.
- 取付けねじ位置：各カメラによって取付けねじ穴位置が異なります。そのためカメラホルダーF2は取付けねじが移動できる形式になっています。
- スローシャッターを切る場合には必ずケーブルリリーズをご用意ください。
キヤノンでは長さの異なるケーブルリリーズを2種用意しています。

※製品仕様、および外観は都合により変更することがあります。



Attachment Screw Hole
for Vertical Position use
三脚ねじ穴(縦位置用)

CANON INC.

11-28, Mita 3-chome, Minato-ku, Tokyo 108, Japan

キヤノン株式会社

キヤノン販売株式会社

〒108 東京都港区三田 3-11-28

カメラ販売企画部 (03) 455-9353

PUB. NO. IM1016B 1174B1 PRINTED IN JAPAN