

CODE NO.	ITEM
1-21311-28	Canon EF w/lens FD 50mm f/1.8 S.C.
1-21311-29	Canon EF w/lens FD 50mm f/1.8 S.C. in case
1-21311-26	Canon EF w/lens FD 50mm f/1.4 S.S.C.
1-21311-27	Canon EF w/lens FD 50mm f/1.4 S.S.C. in case



1-21311-24	Canon EF w/lens FD 55mm f/1.2 S.S.C.
1-21311-25	Canon EF w/lens FD 55mm f/1.2 S.S.C. in case
1-21311-21	Canon EF Body Only

Total Control in Any Light



DISCONTINUED PRODUCT
 Please retain this section for reference purposes.

SPECIFICATIONS

- **Type:** 35mm single-lens reflex AE (Automatic Exposure) camera with focal plane shutter
- **Picture Size:** 24x36mm
- **Standard Lenses:** Canon FD 55mm f/1.2 S.S.C., FD 50mm f/1.4 S.S.C., FD 50 mm f/1.8 S.C.
- **Interchangeable Lenses:** FD series for AE photography; FL series and R series for stopped-down metering
- **Viewfinder:** fixed eye-level pentaprism
- **Field-of-View:** 92% vert. and 93% hor. of actual picture area; 0.82x magnification at infinity with standard 50mm lens
- **Finder Information:** aperture scale with meter needle, over and underexposure warning marks, stopped-down metering index mark, shutter speed scale and indicator
- **Focusing Screen:** center spot micropism surrounded by plain ground glass ring and spot glass/fresnel field
- **Eye-piece Accessories:** angle finders, magnifier, 4 strengths of dioptic adjustment lenses, eyecup
- **Mirror:** instant-return type
- **Electro-Mechanical Shutter:** vertically-moving metal focal plane shutter, 1/2-1/1,000 sec. and B in 11 steps (mechanically controlled); 30-1 sec. in 6 steps (electronically controlled)
- **Shutter Speed Dial:** B, 1-1,000 sec. white marking
1/125 sec. (X sync.) orange marking
30-2 sec yellow marking
- **Slow Shutter Speed Indicator:** Light Emitting Diode (LED) flashes when shutter speeds from 1-30 sec. are used.
- **Self-Timer:** The built-in self-timer is activated by the shutter button with a time lag of approximately 10 sec. A self-timer lock button prevents unintentional operation.
- **Exposure Adjustment:** Variable Aperture (shutter-preferred) AE with FD lenses. The aperture is adjusted automatically after shutter speed and ASA are set. Central Emphasis Metering gives an average reading of the screen brightness with more emphasis on the center portion, utilizing wide range Silicon Photocell.
- **Exposure Meter Range:** EV-2 (f/1.4, 8 sec.) to EV18 (f/16, 1/1,000 sec.) with ASA 100 film;
- **Film Speed Range:** ASA 12-3,200
- **Function of Lenses:** FD lenses: full aperture metering, coupled

- with automatic diaphragm and AE operation. FL lenses: stopped-down metering, coupled with automatic diaphragm. R lenses: stopped-down metering, manually-operated diaphragm
- **Power Source:** two 1.3V mercury batteries (Mallory PX625, Eveready EPX625)
- **Battery Check:** LED flashes when battery check button is depressed if power is sufficient.
- **AE Memory Lock:** The f/stop set by the Variable Aperture AE control may be locked in by pressing a button.
- **Flash Synchronization:** X synchronization at 1/125 sec. and below; M, MF and FP bulb synchronization at 1/15 sec. and below
- **Flash:** Built-in hot shoe has direct contacts for Canon Auto Tuning (CAT) System. The sync. terminal with a built-in cover is on the left end of the camera body.
- **Canon Auto Tuning:** Possible by combination of the Flash Auto Ring A2 or B2 and the Speedlite 133D. According to the ASA and focused distance, the aperture is adjusted automatically with the selected f/stop indicated in the viewfinder. CAT usable with these lenses: FD50mm f/1.4 S.S.C., FD50mm f/1.8 S.C., FD35mm f/2 S.S.C. and FD35mm f/3.5 S.C.
- **Multiple Exposures:** Possible by depressing the multiple exposure button while operating the winding lever. Operation may be repeated any number of times. The frame counter remains stationary during multiple exposures.
- **Lens Mount:** Canon Breech-Lock
- **Depth-of-Field Preview:** Possible by pressing the multi-purpose lever after manually setting the aperture ring and cocking the shutter.
- **Automatic Blank Shot Mechanism:** Film may be advanced to frame No. 1 by simply using the winding lever, without tripping the shutter each time.
- **Film Loading:** easy film loading with multi-slot take-up spool
- **Winding Lever:** single stroke, 120° throw, 15° standoff; Winding lever moves to standoff position when camera is turned on.
- **Film Rewinding:** Performed by the rewind button and crank.
- **Frame Counter:** S-1-38; Automatically resets when back cover is opened.
- **Dimensions:** body only: 151x96x48mm (5¹⁵/₁₆"x3³/₄"x1⁷/₈"). With f/1.4 lens:151x96x100mm(5¹⁵/₁₆"x3³/₄"x3¹⁵/₁₆"")1,045g(2lbs.5ozs.)

ACCESSORIES

VIEWFINDERS AND ACCESSORIES

CODE NO.	DESCRIPTION
5-40701-22	Magnifier S
5-41041-00	Magnifier Adaptor S
5-40712-00	Angle Finder A-2
5-40711-00	Angle Finder B
5-59212-00	Eye Cup 4S

DIOPTRIC ADJUSTMENT LENSES

5-05072-00	Dioptric Adjustment Lens S (+3)
5-05073-00	Dioptric Adjustment Lens S (+2)
5-05051-00	Dioptric Adjustment Lens S (+1.5)
5-05075-00	Dioptric Adjustment Lens S (+1)
5-05076-00	Dioptric Adjustment Lens S (+0.5)
5-05041-00	Dioptric Adjustment Lens S (0)
5-05078-00	Dioptric Adjustment Lens S (-0.5)
5-05079-00	Dioptric Adjustment Lens S (-2)
5-05081-00	Dioptric Adjustment Lens S (-3)
5-05082-00	Dioptric Adjustment Lens S (-4)

FLASH ACCESSORIES

5-00271-31	Speedlite 133D w/Flash Auto Ring A2 (for 50mm f1.8, 35mm f3.5, 35mm f2.0)
5-00271-32	Speedlite 133D w/Flash Auto Ring B2 (for 50mm f1.4, 35mm f3.5, 35mm f2.0)
5-02124-00	Flash Auto Ring A2
5-02125-00	Flash Auto Ring B2

GADGET BAGS

4-80024-00	Gadget Bag 4
4-80025-00	Gadget Bag G-1

MISCELLANEOUS ACCESSORIES

5-03111-00	Camera Holder F
5-63061-00	Release 30
5-63062-00	Release 50

CASES

4-60822-00	Case L for EF (for 55mm f1.2 lens)
4-60821-00	Case S for EF (for 50mm f1.4, f 1.8 lens)

MACROPHOTO & CLOSE-UP ACCESSORIES

4-20601-20	Copy Stand 4
4-25901-03	Handy Stand F55 set
4-26201-20	Photo Micro Unit F
4-25117-00	Macro Hood
4-25501-00	Microphoto Hood
4-25301-01	Extension Tube ABC Set
4-25301-00	Extension Tube A
4-25302-00	Extension Tube B

CODE NO.	DESCRIPTION
4-25303-00	Extension Tube C
4-25304-00	Extension Tube 25
4-25305-00	Extension Tube 50
4-25311-00	Extension Tube 75
4-25312-00	Extension Tube 100
4-25313-00	Extension Tube 150
4-25314-00	Extension Tube 200
4-25315-00	Extension Tube FL15
4-25321-00	Extension Tube FL25
4-25316-01	Extension Tube M Set
4-25316-00	Extension Tube M5
4-25317-00	Extension Tube M10
4-25322-00	Extension Tube M20
4-25403-00	55 Macrophoto Coupler
4-25404-00	58 Macrophoto Coupler
4-25405-00	48 Macrophoto Coupler
4-25701-00	FL48 Macrophoto Coupler
4-25711-00	FL58 Macrophoto Coupler
4-25721-00	FL55 Macrophoto Coupler
5-42011-00	Lens Mount Converter A
5-42021-00	Lens Mount Converter B
5-42031-00	Lens Mount Converter E
5-42071-00	Lens Mount Converter P
5-43231-01	58 Close-Up 450
5-43241-01	58 Close-Up 240
5-43251-01	48 Close-Up 450
5-43331-01	48 Close-Up 240
5-43571-00	55 Close-Up 450
5-43561-00	55 Close-Up 240
5-59042-20	Bellows FL
5-59043-00	Bellows M
5-59181-00	Slide Duplicator 48
5-59181-01	Slide Duplicator 55
43-6370	Attachment Ring 48 for Slide Duplicator
43-6371	Attachment Ring 55 for Slide Duplicator
43-6372	Attachment Ring 58 for Slide duplicator

BODY COVER

4-52021-00	Camera Cover R-F
------------	------------------

STRAP

5-61131-00	Neck Strap 6 with pad
------------	-----------------------