



交換レンズの使い方

キヤノン EXレンズの後群系を、カメラ側に残す、前群交換式を採用しています。
交換レンズの種類は、標準レンズのほか広角 EX 35mm F 3.5 ならびに望遠 EX 95mm F 3.5 が用意されています。

レンズの交換

- 1 フォーカシングリング前のレンズ枠を、左回して取外します。
- 2 カメラ側に残ったフォーカシングリングの無限遠マーク(∞)が指標位置にあるのを確かめ、交換すべきレンズの底蓋を外し、カメラ側マウントに 右回しで取付けます。

- レンズ交換は、速やかに、直射日光を避けておこなってください。
- 取外したレンズは、直ちにレンズキャップならびに底蓋(ダストキャップ)をしてください。レンズ前面および後端にきずや埃りのつくのを防ぎます。

距離目盛の調整と読み方

カメラ側の目盛は必ず∞に合わせておくこと

- 1 取付けたレンズの距離リングを回して、距離目盛の無限遠マークを、フォーカシングリング先端の距離指標(・)に合わせます。
- 2 ピントの調節は、フォーカシングリングを回転させておこないますが、距離目盛は標準レンズの場合と異なり、レンズ側に目盛られていますから、

フォーカシングリング先端の距離指標を基準に読み取ります。

フィルム感度のセット

* 交換レンズは、いずれも標準レンズと異なる F ナンバー(口径比)をもちます。したがってシャッターダイヤル外周のセッティングを持ち上げ、使用するフィルム感度をレンズの F ナンバーに合わせます。

Uses of Convertible Lenses

The lenses are of the front component convertible type. The rear component of the optical system and diaphragm are built into the camera body.

Changing Lenses

- 1 Remove the front component of the lens by turning it counter-clockwise.
- 2 Set the infinity mark (∞) of the distance scale for the standard lens on the camera body side at the orange line indicator. Turn the focusing ring clockwise as far as possible.
- 3 Mount the lens to be replaced by turning clockwise until it is securely in place.
- 4 Adjust the ASA film speed scale whenever replacing the lens with a different lens speed.

■ Attach the lens quickly in the shade.

■ Whenever a lens is removed, be sure to put on its lens cap and dust cap.

Setting Distance Scale of Convertible Lenses

When using the 35mm wide-angle, 95mm or 125mm telephoto lens, be sure to set its distance scale on the front component properly.

- 1 After replacing the lens, set the infinity mark (∞) of the distance scale for the standard lens on the camera body side at the orange line indicator.
 - 2 Rotate the distance scale on the front component and set the infinity mark (∞) of the distance scale for the 35mm, 95mm or 125mm lens at the white index on the focusing ring.
 - 3 Set the focus by turning the focusing ring. Read the distance scale on the front component with the white index.
- Be sure not to turn the adjusted distance scale on the front component. If the position of the distance scale is moved, correct distance cannot be read off.

キヤノン株式会社

東京都中央区銀座5-9-9

CANON INC.

9-9, Ginza 5-chome, Chuo-ku, Tokyo 104, Japan
PUB. K2060-1035E 0870N2.3 PRINTED IN JAPAN

